

MANUAL DE INSTALACIÓN Y DEL USUARIO

Unidad evaporadora High Wall Unidad interior MULTI VRX de 2da generación



Lea atentamente este manual antes de utilizar el producto y consérvelo a mano para futuras consultas. La imagen del producto en la portada es sólo para referencia.







MODELOS

UAVHWH009DD300E1/I
UAVHWH012DD300E1/I
UAVHWH018DD300E1/I
UAVHWH028DD300E1/I







Preface

Dear users,

Thank you for purchasing and using our product. Please read this manual carefully before you install, use, maintain or troubleshoot this product so that you can familiarize yourself with the product and use it correctly.

For ODUs or other IDUs, please refer to the applicable installation & owner's manuals provided with them.

For detailed operation of auxiliary control devices, such as wired, remote and centralized controllers, please refer to their instructions.

To ensure the correct installation and operation of the product, the following instructions are provided:

- To ensure the correct and safe operation of the product, please strictly follow the requirements listed in this manual.
- All figures and contents in this manual are for reference only. Due to continuing product improvement, the specifications are subject to change without notice.
- Regular cleaning and maintenance of the product are required for intended performance and long service life. Each year before using the air conditioner, please contact your local dealer, and we will assign professionals to provide paid services of cleaning, maintenance, and inspection.
- Please retain this manual for future reference.





Contents

| Safety Warning | | 5 |
|--|-------------------------------|----|
| Warning Signs / 5 | Safety Precautions / 6 | |
| Electric Safety Requirements / 7 | Appendix / 7 | |
| Operation | | 1 |
| Operating Precautions / 11 | Optimum Operation / 12 | |
| Symptoms That Are Not Faults / 14 | Display Panel / 16 | |
| Installation | | 17 |
| Installation Precautions / 17 | Product Installation / 23 | |
| Electrical Connection / 42 | Application Control / 55 | |
| Test Run / 60 | | |
| Cleaning, Maintenance and Afte | er-Sales Service | 62 |
| Safety Warning / 62 | Cleaning and Maintenance / 62 | |
| Maintenance of Conventional Parts / 65 | | |





Please thoroughly read and ensure that you fully understand the safety precautions (including the signs and symbols) in this manual, and follow relevant instructions during use to prevent damage to health or property.



Explanation of symbols displayed on the unit

| | WARNING | This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire. |
|---|---------|---|
| | CAUTION | This symbol shows that the operation manual should be read carefully. |
| | CAUTION | This symbol shows that a service personnel should be handling this equipment with reference to the installation manual. |
| i | CAUTION | This symbol shows that information is available such as the operating manual or installation manual. |



Caution: Risk of fire

(for IEC 60335-2-40: 2018 only)



(for IEC/EN 60335-2-40 except IEC 60335-2-40: 2018)



The symbols above is for R32 refrigerant system.

1 Warning Signs

Different marks are used to indicate the levels of hazard severity. Please follow the instructions and ensure safe operation.

[Danger] Failure to observe the warning will result in severe personal injury or death.

[Warning] Failure to observe the warning could result in severe personal injury or death, property damage, or electrical or fire hazards.

Failure to observe the warning could result in minor personal injury, product or property damage, or other unsafe situations.

[Note] Useful operation and maintenance information.











Professional Only

Prohibition signs



No Flammable Materials



No Strong Current



No Open Fire




No Acid or Alkali Materials

2 Safety Precautions

O [Danger]

During thunderstorms, disconnect the main power switch. Otherwise, lightning may damage the unit.

In the event of refrigerant leakage, smoking and open flames are prohibited. Disconnect the main power switch immediately, open windows to allow ventilation, keep away from the leakage point, and contact your local dealer or technical support to request a professional repair.



! [Warning]


Air conditioner installation must comply with local standards and electrical codes, and relevant instructions in this manual.

Do not use any liquid cleanser, liquefied cleanser, or corrosive cleanser to wipe this unit or spray water or other liquids on the unit. Otherwise, the plastic parts of the unit will become damaged and an electrical shock may occur. Disconnect the main power switch before cleaning and maintenance to avoid accidents.

Ask a professional to remove and reinstall the air conditioner.

Ask a professional for maintenance and repair assistance.

The IDU shall be placed at a height not accessible to children, at least 2.5m above the ground.



[Caution]

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

The units are partial unit air conditioners, complying with partial unit requirements of this International Standard, and must only be connected to other units that have been confirmed as complying to corresponding partial unit requirements of this International Standard.





Electric Safety Requirements

[Warning]

The air conditioner shall be installed according to the local wiring specifications.

Wiring work must be completed by qualified electricians.

All wiring work must comply with electrical safety specifications.

The air conditioner must be well grounded. Specifically, the main switch of the air conditioner must have a reliable grounding cable.

Before contacting wiring devices, cut off all the power supplies.

The user MAY NOT disassemble or repair the air conditioner. Doing so can be dangerous. In the event of a fault, immediately cut off the power and contact your local dealer or technical support.

A separate power supply that meets the rated parameter values must be provided for the air conditioner.

The fixed wiring to which the air conditioner is connected must be equipped with a power cut-off device that meets the wiring requirements.

To avoid danger, a damaged power cable must be replaced by professionals from the maintenance department or a similar department of the manufacturer.

The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection.

The specifications of the fuse are printed on the circuit board.

NOTE: For the units with R32 refrigerant, only the blast-proof ceramic fuse can be used.





[Caution]

Always ground the main power switch.

Do not use a damaged power cable and replace it if it is damaged.

When the air conditioner is used for the first time or is in a power-off state for a long time, it needs to be connected to the power supply and warmed up for at least 12 hours before use.





Appendix



[Warning]

The following applies to r32 refrigerant systems.

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.

For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.







The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.

Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the riskof fire or explosion.

All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.

Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period

that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using flammable refrigerants:

- the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures.

If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- -that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- -that no live electrical components and wiring are exposed whiule charging, recovering or purging the system;
- -that there is continuity of earth bonding.

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.

Replacement parts shall be in accordance with the manufacturer's specifications.

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.





Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of ageing or continual vibration from sources such as compressors or fans.

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, it is important that best practice is followed.

Since flammability is a consideration. The following procedure shall be adhered to:

- · remove refrigerant;
- purge the circuit with inert gas;
- · evacuate:
- · purge again with inert gas;
- · open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders. The system shall be "flushed" with OFN to render the unit safe. This process may need to be repeated several times. Compressed air or oxygen shall not be used for this task.

Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

This operation is absolutely vital if brazing operations on the pipe-work are to take place.

Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.

Prior to recharging the system it shall be pressure tested with OFN.

DD.12 Decommissioning:

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with manufacturer's instructions.
- h) Do not overfill cylinders. (No more than 80 % volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect





couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Warning: disconnect the appliance from its power source during service and when replacing parts.

These units are partial unit air conditioners, complying with partial unit requirements of this International Standard, and must only be connected to other units that have been confirmed as complying to corresponding partial unit requirements of this International Standard.





Operation

Operation Precautions

! [Warning]

If the unit will be not used for a long time, disconnect the main power switch. Otherwise, an accident may occur.

The installation height of the air conditioner shall be at least 2.5m above the ground to avoid the following risks:

- 1. Touching of moving or live parts, such as fans, motors, or louvers, by a non professional. Running parts may cause harm to you or transmission assemblies may become damaged.
- 2. Getting too close to the air conditioner may reduce the level of comfort.

When the product is used with a burning appliance, the room must be ventilated regularly. Otherwise, it may cause an insufficient oxygen supply.

Do not let children play with the air conditioner. Otherwise, an accident may occur.

Do not expose the IDUs or controller to moisture or water as this may cause short circuiting or fire.

Do not place any appliance that uses an open flame in the direct air supply of the air conditioner as it could interfere with the combustion of the appliance.

Do not use or store flammable gases or liquids such as natural gas, hair spray, paint or gasoline near the air conditioner. Otherwise, a fire may occur.

To avoid causing harm, do not place animals or plants directly in front of the air conditioner's air supply.

In the event of abnormal conditions such as abnormal noise, smell, smoke, temperature rise, and electric leakage, please cut off the power immediately, and then contact your local dealer or air conditioner customer service center. Do not repair the air conditioner by yourself.

Do not place flammable sprayers near the air conditioner or spray it directly at the air conditioner. Otherwise, a fire may occur.

Do not place a container of water on the air conditioner. If immersed in water, the air conditioner's electrical insulation will weaken, resulting in electrical shock.

After long-term use, confirm whether the installation platform has become worn. If it is worn, the unit could fall, causing injury.

Do not operate the switch with wet hands, as this may result in electric shock.

When servicing the air conditioner, be sure to turn off the air conditioner and cut off the power supply. Otherwise, the high-speed operation of the internal fan will cause injury.

The air conditioner cannot be used to preserve food, animals and plants, precision instruments and works of art, etc.; otherwise, quality degradation could occur.

Do not use fuses like iron or copper wire other than those with the specified capacity. Otherwise, a malfunction or fire may occur. The power supply must use the special circuit of the air conditioner at the rated voltage.

Do not place valuables under the air conditioner. Air conditioner condensation problems may damage the valuables.

When the air conditioner needs to be moved and re-installed, please entrust the local dealer or a professional technician to operate it.













[Caution]

To use the unit normally, please follow the "Operation" section in this manual. Otherwise, the internal protection may be triggered, the unit may begin to drip, or the unit's cooling and heating effects may be impacted.

The room temperature should be set properly, especially when there are elderly, children, or patients in the room.




Lightning or the starting and stopping of large electrical equipment in nearby factories may cause misoperation of the air conditioner. Please turn off the main power switch for a few seconds, and then restart the air conditioner.

To avoid accidental resetting of the thermal circuit breaker, the air conditioner cannot be powered by an external switching device such as a timer or connected to a circuit that is turned on and off by a common component timer.

Check whether the air filter is installed properly. Confirm that the inlet and outlet ports of the IDU/ODU are not blocked.

If the air conditioner will not be used for a long time, please clean the air filter before starting the air conditioner. Otherwise, dust and mold on the filter could contaminate the air or produce an unpleasant smell. For more details, please refer to the section "Cleaning and Maintenance".




2 Optimum Operation

As cold air sinks and hot air rises, adjust the direction of louvers respectively in cooling and heating modes to ensure good cooling and heating effects.

In Cooling Mode

To improve the cooling effect in the entire room, adjust the louvers of the air outlet grille horizontally.








In Heating Mode

To improve the heating effect in the lower parts of a room, adjust the louvers of air outlet grille downwards.



Operating Range

To maintain good performance, operate the air conditioner under the following temperature conditions:

| | Indoor temperature | 16~32°C |
|---------|--------------------|---|
| Cooling | Indoor humidity | ≤80% (When the humidity exceeds 80%, long-time operation of the IDU may cause dew condensation on the surface of the IDU or generate mist-like cold air from the air outlet.) |
| Heating | Indoor temperature | 15~30°C |



The IDU operates stably within the temperature range given in the table above. If it exceeds this normal operating range, the IDU may stop running.





3

Symptoms That Are Not Faults

Normal Protection of the Air Conditioner

During operation, the following phenomena are normal and do not require maintenance.

Protection

When the power switch is on, if you start the system right after it is stopped, it is normal that the ODU does not operate for about four minutes as frequent compressor start/stop is not supported.

Anti-cold air protection

(Heat pump type)

In heating mode (including heating in automatic mode), when the indoor heat exchanger does not reach a certain temperature, the indoor fan temporarily shuts off, or runs in Low mode until the heat exchanger heats up to prevent the blowing of cold air.

Defrosting

(Heat pump type)

When the outdoor temperature is low and the humidity is high, frost may build up on the ODU's heat exchanger, which may reduce the heating capacity of the air conditioner. In this case, the air conditioner will stop heating, enter automatic defrosting mode, and return to heating mode after defrosting has been completed.

During the defrosting, the outdoor fan stops running and the indoor fan runs using the anti-cold air protection function.

The defrosting operation time varies depending on the outdoor temperature and the degree of frosting. It generally takes 2 to 10 minutes.

During the defrosting process, the ODU may emit steam due to the rapid defrosting, which is normal.

Anticondensation

When the IDU detects high humidity, the air conditioner will adjust the louver angle and the fan speed to prevent condensation and avoid dripping.





Normal Phenomena that Are Not Air Conditioner Faults

The following phenomena are normal during operation of the air conditioner. They can be solved according to the instructions below or do not need to be solved.

■ The IDU emits white mist

- 1. In an environment where the indoor relative humidity is too high, when the IDU runs in cooling mode, white mist may appear due to the humidity and the temperature difference between the air inlet and outlet.
- 2. When the air conditioner is switched to heating mode after defrosting, the IDU discharges the moisture generated from defrosting as steam.

■ The IDU blows dust

When the air conditioner has not been used for a long time or is used for the first time, the air filter should be cleaned. Otherwise, dust that has entered the IDU will be blown out.

■ The IDU emits odor

The IDU absorbs the odors of rooms, furniture or cigarettes, etc., and disperses the odors during operation. It is advised to have the air conditioner cleaned and maintained regularly by professional technicians.

Water drips on the air conditioner surface

When the indoor relative humidity is high, it is normal for condensation or slight water blowing to occur on the surface of the air conditioner.

"Self-cleaning" sound of icing

During self-cleaning, there may be a slight clicking sound for about 10 minutes, indicating that the IDU is freezing, which is normal.

■ The air conditioner makes low noise

- 1. When the air conditioner is in "Auto", "Cool", "Dry", and "Heat" modes, it may emit a low continuous "hissing" sound, which is caused by the refrigerant flowing between the IDU and the ODU.
- 2. A "hissing" sound may be heard for a short time after the air conditioner stops operation or during "defrosting", which is caused when the refrigerant stops flowing or changes its flow.
- 3. When the air conditioner is in Cool mode or Dry mode, a small and continuous rustling sound can be heard, which is caused by the drain pump.
- 4. When the air conditioner starts or stops running, you may hear a squeaking sound which is produced by the expansion or shrinkage of parts or surrounding aesthetic materials due to temperature change. The sound will disappear when the air conditioner is running normally.

Switching from cooling/heating (not available for cooling only units) mode to fan only mode When the IDU reaches the set temperature, the air conditioner compressor automatically stops operation and switches to the fan only mode. When the room temperature rises (in cooling mode) or falls (in heating mode) to a certain level, the compressor is restarted and cooling or heating operation is resumed.

■ In winter, the outdoor temperature is low, and heating effects may be decreased

- 1. During the heating operation of the heat pump type air conditioner, the air conditioner absorbs heat from the outdoor air and releases it to heat the indoor air. This is the heat pump heating principle of the air conditioner.
- 2. When the heat pump runs in heating mode, the ODU blows out cold air, causing the outdoor temperature to drop. When the outdoor temperature is extremely low, the heating capability of the air conditioner drops gradually. You are advised to use other heating devices for heating.


No heating or cooling options

All IDUs in the same air conditioning system can only operate in the same mode, for example, cooling, heating, or others. Conflict may occur if IDUs are set to different modes. Only the IDU that is first started up can determine the operating mode, and those started after it can only follow the operating mode of the first IDU. To change the operating mode, you need to turn off all the IDUs. The operating mode of all IDUs must be the same.





4 Display Panel



Display functions:

- 1 In Standby mode, the main interface displays "---".
- When starting up in Cooling or Heating mode, the main interface displays the set temperature. In Fan mode, the main interface displays the indoor temperature. In Dry mode, the main interface displays the set temperature, and when the humidity is set, the set humidity value is displayed on the wired controller.
- 3 The light display on the main interface can be turned on or off through the light button on the remote controller.
- 4 When the system fails or runs in a special mode, the main interface displays the error code or the special mode running code. For more information, see the "Installation Application Control Error Codes and Meanings" section.



Some display functions are available only for certain IDU and ODU models, wired controllers, and display panels. For further details, please consult your local dealer or technical support staff.





Installation

Carefully read this manual before installing the IDU.

1 Installation Precautions

Qualification and Safety Regulation Requirements



Please carry out the installation according to local standards.

Ask your local dealer or professionals to install the product.

This unit must be installed by professional technicians with relevant specialized knowledge. Users MAY NOT install the unit themselves; otherwise, faulty operations may cause the risks of fire, electrical shock, injury, or leakage, which could harm you or others or damage the air conditioner.

Never modify or repair the unit on your own.

Otherwise, a fire, electric shock, injury or water leakage may occur. Get your local dealer or a professional to do so.

Ensure that the residual current device (RCD) is installed.

The RCD must be installed. Failure to install it may result in electric shock.

When powering the unit, follow the regulations of the local electric company.

Make sure that the unit is grounded reliably in accordance with laws. If the grounding is not completed correctly, it may cause electrical shock.

When moving, disassembling or reinstalling the air conditioner, get the assistance of your local dealer or a professional.

If installed improperly, fire, electrical shock, injury, or water leakage may occur.

Use the optional accessories specified by our company.

The installation of these accessories must be carried out by professionals. Improper installation may cause fire, electrical shock, water leakage and other hazards.

Use only power cables and communication cables that meet specification requirements. Properly connect all the wiring to make sure that no external forces are acting on the terminal blocks, power cables and communication cables. Improper wiring or installation may cause a fire.

The air conditioner must be grounded. Check whether the earth line is securely connected or broken. Do not connect the ground line to gas cans, water piping, lightning rods or telephone earth lines.

The main power switch of the air conditioner should be put in a position that is out of the reach of children.

It should not be obstructed by flammable objects such as curtains.

Open flames are prohibited when refrigerant leaks are present.

If the air conditioner is not cooling/heating properly, this may be caused by a refrigerant leak. If this occurs, contact your local dealer or a professional.

The refrigerant in the air conditioner is safe, and usually does not leak. If there is refrigerant leakage in the room, it is easy for a fire to occur after contact with the heating units of the heater/electric stove/stove. Please disconnect the power supply of the air conditioner, extinguish the flames of appliances that produce a flame, and open the windows and doors of the room to allow ventilation and ensure that the concentration of refrigerant leakage in the room does not exceed a critical level; keep away from the leakage point, and contact the dealer or professional personnel.

After the refrigerant leakage is repaired, do not start the product until the maintenance personnel confirms that the leakage is fully repaired.













Before and after installation, exposing the unit to water or moisture will cause electrical short circuit.

Do not store the unit in a humid basement or expose it to rain or water.

Make sure the installation base and lifting are robust and reliable;

Insecure installation of the base may cause the air conditioner to fall, leading to an accident. Take into full consideration the effects of strong winds, typhoons and earthquakes, and reinforce the installation.

Check whether the drainage pipe can drain the water smoothly.

Improper installation of the pipeline may lead to water leakage that damage the furniture, electric appliances, and carpet.

After installation, check whether the refrigerant is leaking.

Do not install the product in a location where there is a danger of flammable gas leaks. In the event of leakage of combustible gas, the combustible gas surrounding the IDU may cause

Install an air filter of 30-80 mesh/inch at the return air grille to filter dust in the air and keep the air diffuser clean and free from dirt blockage.







a fire.

Keep the IDU, ODU, power cable, and connecting wires at least 1m away from the high-power radio equipment, to prevent electromagnetic interference and noise. For some electromagnetic waves, it is not enough to prevent noise even at a distance of more than 1m.

In a room equipped with fluorescent lamps (rectifier type or fast start type), the signal transmission distance of the remote controller (wireless) may not reach the predetermined value. Install the IDU as far away from the fluorescent lamp as possible.

Do not touch the fins of the heat exchanger, as this could cause injury.

For safety, please dispose of the packing materials properly.

Nails and other packaging materials may cause personal injury or other risks. Tear up the plastic packaging bag and dispose of it properly to prevent children from playing with it, leading to suffocation.

Do not cut off the power supply immediately after the IDU stops running.

Some parts of the IDU like the valve body and water pump are still in operation. Please wait for at least 5 minutes before cutting off the power supply. Otherwise, water leakage and other faults may occur.

For evaporating units and condensing units, the instructions or markings shall include a wording to assure that the maximum operating pressure is considered when connecting to any condenser unit or evaporator unit.

For evaporating units, condensing units and condenser units, the instructions or markings shall include refrigerant charging instructions.

A warning to assure that partial units shall only be connected to an appliance suitable for the same refrigerant.

This unit is a partial unit air conditioner, complying with partial unit requirements of this International Standard, and must only be connected to other units that have been confirmed as complying to corresponding partial unit requirements of this International Standard.

The electrical interfaces shall be specified with purpose, voltage, current, and safety class of construction.

The SELV connection points, if provided, are to be clearly indicated in the instructions.

The connection point should be marked with the "read the instructions" symbol per ISO 7000-0790 (2004-01) and the Class III symbol according to IEC 60417-5180 (2003-02).



This unit is equipped with a refrigerant leak detector for safety. To be effective, the unit must be electrically powered at all times after installation, other than when servicing.

If any supplemental unit is employed to detect leaked refrigerant, such unit shall also apply this marking or be accompanied by such instructions.





Precautions for Carrying and Lifting the Air Conditioner

- 1 Before carrying the air conditioner, determine the route that will be used to move it to the installation site.
- 2 Do not unseal the air conditioner until it is moved to the installation site.
- When unpacking and moving the air conditioner, do not apply force to the refrigerant piping, drainage pipe and plastic accessories, so as to avoid damaging the air conditioner and causing personal injury.
- Before installing the air conditioner, make sure that the refrigerant specified on the nameplate is being used. For the installation of the ODU, refer to the installation instructions in the Installation & Owner's Manual attached with the ODU.

Forbidden Installation Sites



\ [Warning]

Do not install or use the air conditioner in the following places:

A place filled with mineral oil, fumes or mist, like a kitchen.

Plastic parts will age and the heat exchanger will become dirty, eventually causing the air conditioner performance to deteriorate or leak water.



- A place where there are corrosive gases, such as acid or alkaline gases.

 Copper pipes and copper welds will be corroded, resulting in refrigerant leakage.
- A place exposed to combustible gases and using volatile combustible gases such as diluent or gasoline.

The electronics in the air conditioner may cause the surrounding gas to ignite.

- A place where there is equipment emitting electromagnetic radiation.

 The control system will fail and the air conditioner will not function properly.
- A place where there is a high salt content in the air like a coastal area.
- 🗶 A place where an explosion may occur.
- In vehicles or cabin rooms.
- * Factories with major voltage fluctuations in the power supplies.
- ★ Other special environmental conditions.





Air conditioner units of this series are designed to provide comfort. Do not use them in equipment rooms and rooms with precision instruments, food, plants, animals, or works of art.






Recommended Installation Sites

It is recommended to install the air conditioner according to the design drawing of the HVAC engineer.

The selection principle for the installation site is as follows:



Ensure IDU maintenance space.

The nearer the drainage pipe and copper pipe are to the ODU, the lower the pipe cost is.

Prevent the air conditioner from blowing directly at the human body.

The closer the wiring is to the power cabinet, the lower the wiring cost is.

Keep the air-conditioning return air away from direct exposure to the sun in the room.

Be careful not to interfere with the light tank, fire pipe, gas pipe and other facilities.

The IDU should not be installed on load-bearing beams or columns that affect the structural safety of the house.

The wired controller and the IDU should be in the same installation space; otherwise, the sampling point setting of the wired controller needs to be changed.

Choose a site that fully complies with the following conditions and user requirements to install the air conditioning unit:

There is enough space for installation and maintenance.

Airflow in/out of the machine is not obstructed, and the external air exerts minimum impact.

It is easy to supply airflow to every corner of the room.

It is easy to drain fluids from the connected piping and water discharge piping.

There is no direct heat radiation.

Avoid installation in narrow spaces or where there are more stringent noise requirements.

Install the IDU at a place 2.5m above ground.

Condensate water can be discharged smoothly.

The length of the piping between the indoor and ODUs is within the permitted range. Refer to the Installation & Owner's Manual attached with the ODU.





Recommended Installation Sites



Crowded places such as living rooms and offices

The unit is usually installed in a concealed manner, with air supplied on the side and returned at the bottom.

The air outlet must not face areas where people frequently spend time, such as sofas and coffee tables. Instead, the breeze should flow out from the side to increase comfort.



Dining room

As the dining room is generally located next to the kitchen, which is usually filled with oily fumes, the central air conditioner can be installed on the ceiling between the dining room and the kitchen. The air outlet must not face the dining table. Otherwise, dust on the air outlet on the ceiling may be blown onto the food. Keep the return air inlet as far away from the kitchen as possible to avoid intaking oily fumes and affecting the air quality.



Bedroom

The unit can be installed on the ceiling above the bedroom doors or near windows. The air is flexibly supplied on the side and returned at the bottom. Avoid directing streams of air towards the bed if possible.



Install the air conditioner in a location with sufficient strength to support the weight of the unit. Take reinforcement measures when necessary.

The unit may fall and cause personal injury if the location is not strong enough or if the air conditioner is not properly installed.

Before wiring/pipe layout, make sure that the installation area (walls and floor) is safe and free of water, power, gas, and other hidden dangers.

The unit needs to be level and shall not tilt to either side or forward.





Parts

Part Description (kBtu/h≤28)

- 1 Panel assembly
- (4) *Power cable and ground wire

* To be purchased separately on site.

- (7) Upper and lower louvers
- (10) *Connection wire

- 2 Display panel
- (5) Room temperature sensor
- (8) Filter
- (11) Wired controller (optional)
- (3) Panel frame
- (6) Electric control parts
- 9 Left and right louver parts (optional)
- 12) Remote controller (optional)

[Warning]

When installing the unit, remember to remove the protective film of the display panel and sticker attached, otherwise the display effect will be affected.





Display panel



All the optional accessories should be from our company.

For optional accessories such as wired controllers, please refer to the instructions of the product.

All the figures in the manual explain only the general appearance and functions of the product. The appearance and functions of the product you purchased may not be completely consistent with those listed in the figures. Please refer to the actual product.






2 Product Installation

(Unit: mm)

Product Dimensions

kBtu/h≤28:




| Capacity(kBtu/h) | А | В | С | D | Е |
|--|------|-----|-----|------|------|
| kBtu/h≤12 | 750 | 295 | 265 | 581 | 736 |
| 12 <kbtu h≤18<="" td=""><td>950</td><td>295</td><td>265</td><td>781</td><td>936</td></kbtu> | 950 | 295 | 265 | 781 | 936 |
| 18 <kbtu h≤28<="" td=""><td>1200</td><td>295</td><td>265</td><td>1025</td><td>1186</td></kbtu> | 1200 | 295 | 265 | 1025 | 1186 |






Installation Distance

kBtu/h≤28:






Pipe Routing Direction

The refrigerant pipe can be routed from four directions: left, left rear, right, and right rear; drainage pipe can be routed from six directions: left, left rear, right, right rear, upper left, and upper right. The upper left and upper right directions are only applicable to drainage pipe of the water pump.

If pipes are routed from left, right, upper left or upper right directions, cut holes through the panel frame accordingly.


Refrigerant pipe routing direction








Drainage pipe routing direction



Instructions on Cutting Left and Right Knockouts

kBtu/h≤28:







Installation Board Positioning

kBtu/h≤28: Ε Ceiling ᠒ Wall φ108 Wall hole Fixing screw hole 296 cover Onsite piping Liquid pipe Gas pipe φ65 Wall hole Α 400 Α В С Left pipe Right pipe

| Distance | A | В | С | D | E | Reserved leng cable and si | • |
|--|-----|------|------|-----|-----|-------------------------------|------------|
| Capacity(kBtu/h) | | | | | | Left pipe | Right pipe |
| kBtu/h≤12 | 100 | ≥225 | ≥225 | ≥30 | 230 | ≥1115 | ≥415 |
| 12 <kbtu h≤18<="" td=""><td>180</td><td>≥325</td><td>≥325</td><td>≥30</td><td>412</td><td>≥1315</td><td>≥415</td></kbtu> | 180 | ≥325 | ≥325 | ≥30 | 412 | ≥1315 | ≥415 |
| 18 <kbtu h≤28<="" td=""><td>220</td><td>≥375</td><td>≥375</td><td>≥30</td><td>400</td><td>≥1565</td><td>≥415</td></kbtu> | 220 | ≥375 | ≥375 | ≥30 | 400 | ≥1565 | ≥415 |





Installation Materials

1

Accessories

| List of accessories | | | | |
|--|--|-------------------|------------------------|--------------------------------------|
| Installation & Owner's Manual X 1 IDU Installation Instructions (Make sure to hand it over to the user) | Brass nut X 2 For use in the installation of connecting pipe | Drainage hose X 1 | Installation board X 1 | Rubber sleeve of expansion screw X 4 |
| Wall hole sleeve X 1 | Wall hole sleeve cover X 1 | Binding tie X 1 | Power cable clamp X 2 | Screw ST3.9*25 X 4 |
| Screw ST3.9*6.5 X 4 | | | | |

Check the accessory kit for the above items and contact your local dealer for any missing items.

Do not throw away any accessories that may be required for installation until the installation is complete.

Wired/remote controller is optional and needs to be purchased separately.

2 Locally Purchased Accessories

| | Connecting piping (unit: mm) | | | |
|--------|--|--|--|--|
| | Capacity(kBtu/h) | Liquid side | Gas side | |
| | kBtu/h≤18 | Ф6.35×0.75 | Ф12.7×0.75 | |
| | 18 <kbtu h≤28<="" td=""><td>Ф9.52×0.75</td><td>Ф15.9×1.0</td></kbtu> | Ф9.52×0.75 | Ф15.9×1.0 | |
| CC006/ | Remarks | For connection of the IDU refrigerant system, it is recommended to use a soft copper tube (T2M), with the length selected according to the actual situation. | | |
| | Drainage hose | | Thermal insulation pipe | |
| | This is used to extend the IDU's drainage pipe, 16mm in external diameter. The length is determined according to actual needs. | | The thickness of the insulation pipe for the copper pipe is usually 15mm or above; and the thickness of the insulation pipe for the UPVC plastic tube is usually 10mm or above. If the pipe is used in a closed humid area, the thickness should be increased. | |

[Caution]

Materials, including copper pipes, drainage hoses, various fasteners (such as pipe supports, clamps, and screws), power cables, and signal cables to be used for field installation need to be purchased on site by the installation operator. Materials and specifications must comply with relevant national or industry standards.







Heat Insulation Material Requirements

Copper pipe insulation

- ① Use the closed-cell foam insulation material, which is rated at a flame retardancy level of B1 and heat resistance of over 120 ℃.
- 2 Thickness of the insulation pipe:
 - 1. When the diameter of the copper pipe is equal to or greater than 15.9mm, the insulation thickness is at least 20mm.
 - 2. When the diameter of the copper pipe is equal to or smaller than 12.7mm, the insulation thickness is at least 15mm.
- ③ For insulation of the outdoor copper pipe, the wall thickness of insulation pipes for winter heating systems is generally thickened to over 40mm in regions with severe cold. For insulation of the indoor gas pipe, the wall thickness of insulation pipes is usually greater than 20mm.



The materials and specifications of insulation materials must meet national or industry standards.


Installation Operation



Check Before Installation

Unpacking Check

- ① Before installation, check whether the packing materials are in good condition, whether the accessories that come with the product are complete, whether the air conditioner is intact, whether the surfaces of the heat exchanger and other parts have become worn, and whether there are oil stains on the check valve of the unit.
- ② Check the two sealing nuts of the refrigerant pipe, and observe whether the red dot on the surface of the sealing nut of the gas pipe bulges. If it bulges, the pipe is well sealed; if it retracts, the line is leaking, and you need to contact your local dealer.
- (3) Check the machine model before installation.
- After IDU and ODU inspection, pack them with plastic bags to avoid intake of foreign matters.



Refrigerant Connecting Piping Installation



Length and Level Difference Requirements for the Pipe Connections of IDU and ODU

Different ODUs have different requirements for length and level differences for the piping. Refer to the Installation & Owner's Manual attached with the ODU.



[Warning]

During the installation of the connecting pipes, do not allow air, dust, and other debris to penetrate the piping system, and make sure the interior of the pipes is dry.

Install the connecting pipes only when the IDUs and ODUs are secured.

When installing the connecting pipes, record the actual installation length of the liquid pipe on the spot so that additional refrigerant can be added.

The copper pipes must be wrapped with thermal insulation materials when they are installed.

In the event of refrigerant gas leakage during operation, please ventilate immediately.






Pipe Layout

Bend the pipes or punch holes in the wall as needed. The deformed pipe area must not exceed 15% of the total area. A protective casing should be installed at the wall or floor hole. The weld joint must not be inside the casing. The drill hole on the external wall must be sealed and tightly wrapped with a binding tie to prevent impurities from entering the pipe. The pipe must be insulated with the correctly-sized insulation pipe.



Note: D1 is the minimum diameter, and D2 is the nominal diameter.

The wrapped connecting pipe is plugged through the wall hole sleeve from the outdoor side and enters the indoor side. The pipes must be arranged carefully so as not to damage the piping.




3 Pipe Connection Steps

Measure the required length of the connecting pipe. Make the connecting pipe using the following method (see "Pipe Connection" for details).

Connect the IDU first, then connect the ODU.

Before tightening the flare nut, apply refrigeration oil on the inner and outer surface of the pipe flare (you must use refrigeration oil compatible with the refrigerant for this model), and tighten it 3 or 4 turns by hand. When connecting or removing a pipe, use two wrenches at the same time.



[Caution]

Bend and arrange pipes carefully without damaging the pipes and their insulating layers.

Do not let the interface of the IDU bear the weight of the connecting pipe; otherwise, the connecting pipe may be crushed and deformed, which will affect the cooling (heating) effect, or the thermal insulation materials may be compressed, resulting in air leakage and condensation.





- The check valve of the ODU is completely closed when leaving the factory. Unscrew the nuts from the check valve in each connection, and connect the flared tube within 5 minutes. When the nuts at the check valve are removed and placed somewhere for too long, dust and other sundries may enter the pipeline system and cause failures after extended operation.
- After the refrigerant piping is connected to the IDU and ODU, follow the operations in "Vacuum pumping" to exhaust the air. After the air is exhausted, tighten the maintenance nut.



Pipe Connection

Bend the pipe with your thumb



Processing method

- Hand bending processing: Applicable to thin copper pipes (φ6.35mm-φ12.7mm).
- Mechanical bending processing: Wider application (φ6.35-φ28.6mm), using a spring pipe bender, manual pipe bender or electric pipe bender.



When bending pipes, the copper pipes shall not be wrinkled or deformed on the inside.

When a spring pipe bender is used, clean it before it is inserted into the copper pipe.

The bending angle should not exceed 90°; otherwise, wrinkles will form in the pipe, which increases the likelihood of breakage.

Do not leave any dents in the pipe when you bend the pipe. The cross-sectional area of the bent pipe must exceed 2/3 of the original pipe section.

1. Brazing pipes

When brazing pipes, fill the pipes with nitrogen. First evenly heat the inner pipes, then the outer pipes, and fill the joints with welding material.

[Caution]

Nitrogen pressure is kept at about 0.2–0.3kgf/cm² during welding.

Use nitrogen for welding. Do not use flammable gas such as oxygen to avoid the risk of explosion.

Use a pressure relief valve to keep the nitrogen pressure at 0.2kgf/cm².


Select an appropriate position to add nitrogen.

Make sure that the nitrogen passes the welding spot.

If there is a long distance between the position of adding nitrogen and the welding spot, keep adding the nitrogen for a while until oxygen at the welding spot is completely removed.

After welding is completed, continue adding nitrogen until the pipe becomes cool.

Perform welding downwards or horizontally from either side.









2. Flaring

To cut the piping with a pipe cutter, rotate the pipe cutter repeatedly.

Put the pipe into the connecting nut flaring, and both the gas pipe and liquid pipe of the IDU are connected by flaring.






| Outer diameter | A (mm) | | |
|----------------|--------|------|--|
| (mm) | Max. | Min. | |
| Ф6.35 | 8.7 | 8.3 | |
| Ф9.52 | 12.4 | 12.0 | |
| Ф12.7 | 15.8 | 15.4 | |
| Ф15.9 | 19.1 | 18.6 | |
| Ф19.1 | 23.3 | 22.9 | |

3. Nut fastening

- Align the connecting piping, firstly tighten most of the thread of the connecting nut by hand, and then use a wrench to tighten the last 1-2 turns of the thread as shown in the figure.
- The welding is done on site, and the bell mouth cannot be used indoors.(For IEC/EN 60335-2-40 except IEC 60335-2-40: 2018)
- The protective nut is a one-time part, it can not be reused. In case it is removed, it should be replaced with a new one.(For IEC 60335-2-40: 2018 only)





Excessive torque can break nut on installation conditions.

When flared joints are reused indoors, the flare part should be re-fabricated.





| Pipe size (mm) | Tightening torque [N.m (kgf.cm)] |
|----------------|-----------------------------------|
| Ф6.35 | 14.2–17.2 (144–176) |
| Ф9.52 | 32.7–39.9 (333–407) |
| Ф12.7 | 49.5–60.3 (504–616) |
| Ф15.9 | 61.8–75.4 (630–770) |
| Ф19.1 | 97.2–118.6 (990–1210) |

[Caution]

Depending on the installation conditions, excessive torque will damage the flared mouth, and too small torque cannot tighten the nut, which will cause refrigerant leakage. Please refer to the above table to determine the appropriate tightening torque.

Refrigerant Piping Fixing


Angle iron brackets or round steel hangers should be used for fixing. When the liquid pipe and gas pipe are suspended together, the size of the liquid pipe shall prevail.

| Outer diameter of copper pipe (mm) | ≤20 | 20~40 | ≥40 |
|------------------------------------|-----|-------|-----|
| Horizontal pipe distance (m) | 1.0 | 1.5 | 2.0 |
| Stand pipe distance (m) | 1.5 | 2.0 | 2.5 |



Vacuum Pumping

Connect the refrigerant piping to the gas and liquid pipes of the ODU, and use a vacuum pump to evacuate the gas and liquid pipes of the ODU at the same time.





[Caution]

Do not use the refrigerant enclosed in the ODU for vacuuming. The reduction of ODU refrigerant may cause performance degradation of the air conditioner.



Leak Detection

Fill the system with nitrogen and increase its pressure to detect leaks. The following methods are recommended:

1. By foam

Apply soapy water or foam evenly (spray) on areas where leakage may occur, and observe whether air bubbles appear. If there are no air bubbles, it indicates that the system is airtight.

2. By instrument

Use a refrigerant leak detector to identify leaks. Align the leak detector probe with the part where leakage may occur, and follow the instructions to determine whether there is a leak.







Leak detection will be conducted at each spot for at least 3 minutes. If any leak has been identified, tighten the nut and perform the detection again until no leaks are found. After completing the leak detection, wrap the exposed IDU pipe joint with insulation material and tie it with a binding tie to prevent condensation and dripping water.



Heat Insulation Treatment


Pipes the liquid and air sides have a low temperature during cooling. Take sufficient insulation measures to prevent condensation.



Be sure to use a thermal insulation material with a heat resistance of 120°C or higher for the gas pipe.

The attached insulation material for the part of the IDU where the pipe connects must undergo heat insulation treatment that leaves no gaps.

Thermal insulation materials directly exposed to the open air will degrade and lose their insulating properties. For outdoor pipelines, additional protective treatments should be performed, such as adding metal duct boxes.



1. Steps of insulating refrigerant piping



Connecting parts: For example, brazing area, flare, or flange connection shall be insulated after passing the air tightness test.

- 2. Reasons why refrigerant piping shall be insulated
- (1) The gas pipes and liquid pipes can become extremely hot or cool while in operation. Therefore, they should be insulated. Otherwise, the cooling and heating effects will be seriously impacted, and the compressor may become burnt.
- (2) The gas pipes are cold when the unit operates in cooling mode. If they are not properly insulated, they may cause condensation and water leakage.
- (3) The outlet pipe (gas pipe) is hot (usually 50–100 ℃) when the unit operates in heating mode, and accidental contact with the pipe will cause burns. To avoid burns, the pipes should be insulated.
- 3. Selection of insulation materials for refrigerant piping

Use the closed-cell foam insulation material, which has a flame retardant level of B1 and heat resistance of over 120 ℃.

4. Thickness of the insulation layer

When the outer diameter d of the copper pipe is not greater than Φ 12.7mm, the thickness δ of insulation layer is greater than 15mm.

When the outer diameter d of the copper pipe is not smaller than Φ 15.9mm, the thickness δ of insulation layer is greater than 20mm.



The above thickness should be increased if the place is hot and humid.

The pipes outdoors should be protected by metal covers to avoid sunlight, rain, weathering, external force or artificial damage.







5. Installation and insulation tips

(1) Wrong

The gas pipe and the liquid pipe are insulated together, which reduces the heating or cooling effects.








(2) Correct


a. Insulate the gas pipe and the liquid pipe separately.



[Caution]

After the gas pipe and the liquid pipe are insulated separately, binding them too tight may damage the insulation materials already connected. Binding with ties is not recommended.

b. Pipe connectors shall be properly insulated.



[Caution]

No gaps shall be left at the place where insulation materials connect.


If the connecting sections of insulation materials are pulled too much, or wrapped too tightly, these sections are likely to shrink and leave gaps, causing condensation and dripping. Tight wrapping may squeeze out the air in the materials and reduce the insulation effects. In addition, the adhesive tape tends to age and peel off over time.

There is no need to wrap the concealed sections indoors with a binding tie, otherwise the insulation effect will be reduced.





Steps to repair protection sponge: (see the figure below)



Cut a section of protection sponge longer than the gap, pull open the two ends, insert the protection sponge, and apply glue to the joint.




Tips for repairing insulation layer:

- 1. The length of the protection sponge for repair (protection sponge used to fill the gap) must be 5–10 cm longer than the gap.
- 2. The protection sponge for repair must be cut neatly.
- 3. Tightly insert the protection sponge for repair into the gap.
- 4. All the sectional areas and cuts must be glued.
- 5. Wrap the joints with tape.
- 6. There is no need to wrap the concealed sections with a binding tie, otherwise the insulation effect will be reduced.

[Caution]

When installing the insulation pipe on site, please cut it according to the actual needs. (Either method (a) or (b) is OK. Method (c) is incorrect. There must be no gap between the insulation pipe and copper pipe.)







Installation of Drainage Hose

[Caution]

Before installation of the condensate pipeline, determine its direction and elevation to avoid intersection with other pipelines to ensure that the slope is smooth and straight.

The highest point of the drainage pipe should be equipped with a discharge port to ensure the smooth discharge of condensate water, and the discharge port must face downwards to prevent dirt from entering the pipe.

Do not connect the drainage pipe to the wastewater pipe, sewage pipe, or other pipes that produce corrosive gases or odors. Otherwise, the IDU (especially the heat exchanger) may be corroded and odor may enter the room, negatively impacting the heat exchange effects and user experience. The user will assume responsibility for any consequences resulting from failure to abide by instructions.

After the pipeline connection is completed, a water test and a full water test should be done to check whether the drainage is smooth and whether the pipeline system leaks.

The air conditioner drainage pipe must be installed separately from other sewage pipes, rainwater pipes and drainage pipes in the building.

Adverse slope, convex and concave pipes are prohibited, as improper airflow will cause poor drainage.

Drainage hoses need to be evenly wrapped with thermal insulation pipes to prevent condensation.

Please connect the drainage pipes in the following ways. Improper installation of the pipes may result in water leakage and damage to furniture and property.

All joints of the drainage system must be sealed to prevent water leakage.




Install the drainage hose.

- 1) Connect the drainage hose to the water outlet pipe of the IDU.
- ② Wrap the joint with waterproof tape, cover the exposed drainage hoses with insulation material, and tie them with a binding tie.
- ③ Insert the end of the drainage hose outdoors into the drainage pipe.



The drainage hose is at the outer layer of the IDU drainage pipe. Try to connect the two pipes till the end.









1 Selection of drainage outlet

kBtu/h≤28:



[Caution]

For models without drain pumps, a water outlet pipe is connected to the natural drainage outlet when the unit leaves factory. For models with drain pumps, a water outlet pipe is connected to the drainage outlet of the drain pump, with natural drainage outlet sealed using a drainage plug, when the unit leaves the factory. Models with drain pumps need to be customized.




(Only applicable to models with water pumps)

2 Connection method of the drainage pipe

(Unit: mm)


• Method to discharge water with the natural drainage outlet:







· Method to discharge water with the drain pump:




[Caution]

Requirements for slope of the drainage pipe:

- 1 The branch pipes of the drainage pipe shall have a slope of at least 1% that follows the direction of water flow. Lifting bolts shall be placed every 1–1.5m at a horizontal pipe and every 1.5–2.0m at a vertical pipe. Each vertical pipe shall have at least two fixing points for branch pipes and lifting bolts.
- ② Adverse slopes are prohibited, and no water may accumulate in the elbow pipe. The outlet end shall not be immersed in liquid.


3 Installation requirement for drainage pipe

The drainage pipe must be inclined downward (1/100 or above) to avoid condensate water flow.






























2 Extend the drainage pipe.

1 To extend the length of a drainage pipe, you need to purchase an extension drainage hose locally. Make sure the extension portion of the drainage hose indoors undergoes heat insulation treatment.



Indoor parts of the drainage pipe shall be insulated to prevent condensation, and protective sleeves should be thicker than 10mm.


If the pipe is not wholly insulated, be sure to rebind the cut part.

Use glue or buckles to connect the joints and cuts of the thermal insulation pipe, and make sure it is at the top of the pipe.

After the drainage test shows that there are no leaks, carry out the insulation of the drainage pipe.

3 Lay and insulate pipes.

- ① Straighten and place the connecting pipes on the floor, and lay the drainage pipe and various cables (remember to distinguish the two ends of the cable) around the connecting pipes.
- ② Measure and adjust the distances of the low-pressure pipe, high-pressure pipe and various cables based on the mouth of the drainage pipe, and bind them together with cable ties.
- ③ Sort the pipes and cables in the following sequence: drainage pipe at the bottom, connecting pipe in the middle, and power cable at the top.
- 4 Start wrapping from the drainage pipe and tie a fast knot.



Note: If the drainage pipe is wrapped above the piping, it may cause poor drainage or backflow of water.

☐ [Note]

The number and type of cables may vary from model to model.

Both ends of the cable are different, so make sure the cable end is correct before binding the pipes.


The binding shall be seamless and neat in appearance.





Hang the IDU.


- ① Pass the properly bundled pipeline and connection lines through the wall hole, making sure that the pipe socket is not damaged, and that the connecting pipes of the unit are free of sand and dust.
- ② Hang the buckle at the back of the indoor unit on the upper hooker of the installation board. Shift the indoor unit left and right to check that the unit is securely and firmly mounted.
- ③ Push the lower part of the indoor unit against the wall, and shift the unit body up and down and left and right to check that the connection is secure.
- 4 Until the indoor unit can be connected properly, make sure that the indoor unit is buckled into the slots. Use your hands to shake the unit to check that it does not move up, down, left or right. Use a spirit level to verify that the indoor unit is level.





Install sealant and wall hole sleeve cover.

- 1) Arrange the wrapped pipes.
- 2 Apply the sealant to the gap between the pipe and wall and press it tightly.
- ③ Pull open the wall hole sleeve cover, and insert the pipe through the hole until it is pressed against the wall.







Perform drainage test.

Drainage

- ① Open the panel assembly and remove the filter.
- 2 Fill the fins of the heat exchanger with water.
- 3 After confirming that the drainage is smooth and free of water leakage, install the filter and close the panel assembly.









3 Electrical Connection

O [Danger]

The power supply must be cut off before any electrical work is carried out. Do not conduct electrical work when the power is on; otherwise, it may cause serious personal injury.

The air conditioning unit must be grounded reliably and must meet the requirements of the local country/region. If the grounding is not reliable, serious personal injury due to electric leakage may occur.

! [Warning]

Installation, inspection or maintenance operations must be completed by professional technicians. All parts and materials must comply with the relevant regulations of the local country/region.

The air conditioning unit must be equipped with a special power supply, and the power supply voltage should conform to the nominal working voltage range of the air conditioning unit.

The power supply of the air conditioning unit must be equipped with a power disconnect device that conforms to the requirements of relevant local technical standards for electrical equipment. The power disconnecting device must have the functions of short circuit protection, overload protection and electric leakage protection. The clearance between open contacts of the power disconnecting device shall be at least 3mm.

The core of the power cable must be made of copper, and the wire diameter should meet the current-carrying requirements. For details, refer to the "Power Cable Diameter and Electric Leakage Protector Selection". A wire diameter that is too small may cause the power cable to heat up, resulting in a fire.

The power cable and the ground wire should be secured reliably to avoid stress on the terminals. Do not pull the power cable forcibly; otherwise, the wiring may become loosened or the terminal blocks may be damaged.

Strong current wires such as power cables cannot be connected to weak current wires such as communication lines; otherwise, the product may become seriously damaged.

Do not bond and connect the power cable. Bonding and connecting the power cable may cause it to heat up, resulting in a fire.

[Caution]

Bonding and connecting the communication line should be avoided, but if it is used, at the very least, ensure a reliable connection by crimping or soldering and make sure the copper wire at the connection is not exposed; otherwise, communication failure may occur.

The power cable and communication line must be routed separately, with a distance of over 5 cm. Otherwise, communication failure may occur.

Keep the vicinity of the air conditioning unit as clean as possible to avoid small animals from nesting and biting the cables. If a small animal touches or bites the cables, short circuiting or electric leakage may occur.

Do not connect the ground wire to the gas pipe, water pipe, lightning rod ground wire or telephone ground wire.

Gas pipe: Risk of explosion and fire when gas leaks.

Water pipe: If rigid plastic pipes are used, there will be no grounding effect.

Lightning rod ground wire or telephone ground wire: In the event of lightning strikes, abnormal ground potential may rise.

After all wiring is completed, check carefully before turning on the power supply.





Electrical Characteristics

| | Electr | Electric specifications of the IDU | | | Indoor Fan Motor | |
|----------------------|-------------------|------------------------------------|------------|------------|---------------------------------|------------|
| Capacity (kBtu/h) | Frequency (Hz) | Voltage (V) | MCA (A) | MFA (A) | Rated Motor Output (W) | FLA (A) |
| 5 | | | 0.28 | 15 | 20 | 0.22 |
| 6 | | 50/60 220~240 | 0.29 | | 20 | 0.23 |
| 7 | | | 0.36 | | 20 | 0.29 |
| 9 | 50/60 | | 0.39 | | 20 | 0.31 |
| 12 | 30/00 | | 0.41 | | 20 | 0.33 |
| 15 | | | 0.51 | | 20 | 0.41 |
| 24 | | | | 0.69 | | 50 |
| 28 | | | 0.98 | | 50 | 0.78 |


Notes:

MCA: Min. Circuit Amps. (A), which is used to select the minimum circuit size to ensure safe operation over a long period of time.

MFA: Max. Fuse Amps. (A), which is used to select the circuit breaker.

FLA: Full Load Amps. (A), which is the full load current of the indoor fan motor (reliable operation at the fastest speed setting).

Schematic diagram of the main terminal blocks of main control board














All weak point connection points meet SELV, such as X1, X2, P, Q, E, CN18 etc.


Wiring

Open the IDU's electric control box cover.

Loosen the screws on the right side of the electric control box cover and remove the electric control box cover.




Connect the strong current wires (power cable, alarm signal output wire, and strong current sterilization wire) and weak current wires (communication line, function expansion board connection wire, remote switch connection wire) to the electric control box through the bottom of the electric control box, and the strong and weak current inlets.







When there is a number of weak current wires, making it impossible for the cable clamp to fix all the wires, please use two ST3.6*6.5 self-tapping screws to fix the power cable clamp from the accessory package on the installation board, and fix those weak current wires that cannot be fixed on the drain pan here.





[Caution]

The strong and weak current wires must be separated.

The use of an adapter board and function expansion board are optional.


Water level switch terminals are shorted when the water level switch is unavailable.



Power cable connection

1. Connection between the power cable and power supply terminal


The power supply terminal of the IDU is fixed on the main control board, the power cable is connected to the power supply terminal labeled "CN1" on the main control board. The live and neutral wires are connected according to the main control board logos "L" and "N", and the ground wire is directly connected to the electric control box sheet metal part.






[Caution]

- Do not bond and connect the power cable. Bonding and connecting the power cable may cause it to heat up, resulting in a fire.
- The power cable must be crimped reliably using an insulated circular terminal block, and then connected to the power supply terminal of the IDU, as shown in the figure below.




If it fails to crimp the insulated circular terminal block due to on-site limitations, connect the power cables of the same diameter to both sides of the power supply terminal block of the IDU, as shown in the figure below.




Do not press the power cables of the same wire diameter on the same side of the terminal. Do not use two power cables of different wire diameters for the same terminal blocks; otherwise, they can easily loosen due to uneven pressure and cause accidents, as shown in the figure below.

















2. Power cable system connection

The communication mode can only use the internal unified power supply mode.









Uniform power supply: All the IDUs in the system are controlled by one circuit breaker.



Communication line connection

1. Selection of communication method for IDUs

The 2nd Generation Atom indoor unit is equipped with RS-485 (PQE) communication, which is compatible with the 1st Generation Atom indoor unit. Before installing the communication line, please select the appropriate communication mode according to the type of internal unit actually purchased and refer to the following table.

| IDU type | Optional communication method between IDUs and ODU | Remarks |
|---|--|---|
| Are all the IDUs in the system 2 nd Generation Atom series | RS-485 (PQ) communication | The IDUs need to be powered uniformly. The communication cables must be connected in serial. Two-core and non-polar communication for PQ. |
| Are some of the IDUs in the system 1st Generation Atom series | RS-485 (PQE) communication | The IDUs need to be powered uniformly. The communication cables must be connected in serial. PQE cables must be 3-core and PQ non-polar. |

2. Table of selection of communication line diameter

| Function | IDU and ODU communication | | One controller to one IDU (two controllers to one IDU) communication | One-to-more (centralized control) communication |
|------------------|--|--|--|---|
| Item | P/Q communication (IDUs are powered uniformly) | P/Q/E communication (IDUs are powered uniformly) | X1X2 communication | D1D2 communication |
| Wire diameter | 2 × 0.75mm² (shielded cable) | 3 × 0.75mm² (shielded cable) | 2 × 0.75mm ² (shielded cable) | 2 × 0.75mm² (shielded cable) |
| Length | ≤ 1200m | ≤ 1200m | ≤ 200m | ≤ 1200m |







Please select the communication line according to the requirements in the above reference table. Use shielded cables for communication when strong magnetism or interference is present.

On-site wiring must comply with the relevant regulations of the local country/region and must be completed by professionals.

Do not connect the communication line when the power is on.

Do not connect the power cable to the communication terminal; otherwise, the main control board may be damaged.

The standard value of the screw torque of the communication line terminal is 0.5N·m. Insufficient torque may cause poor contact; excessive torque may damage the screws and power supply terminals.

If some of the IDUs in the same refrigerant system are 1st Generation Atom series, only P/Q/E communication can be selected for the IDU and ODU communication. The three-core shielded cable of 3×0.75mm² is required to connect "P", "Q", and "E".

Do not bundle the communication line with the refrigerant pipeline, power cable, etc. When the power cable and the communication line are laid in parallel, a distance of more than 5cm should be maintained to prevent interference from the signal source.

Bonding and connecting the communication line should be avoided, but if it is used, at the very least, ensure a reliable connection by crimping or soldering and make sure the copper wire at the connection is not exposed; otherwise, communication failure may occur.






3. IDU and ODU communication


A P/Q communication

Single unit: Use a shielded cable for the P/Q communication and properly ground the shield layer. P and Q ports are located at terminal block "CN6" of the main control board. There is no distinction between negative and positive electrodes. Connect the shield layer to the sheet metal of the electric control box, as shown in the following figure:



Connect to the ODU PQ

System: The maximum total length of the P/Q communication cable of the IDU and ODU can be up to 1200m, and can be connected in serial, as shown in the figure below:








B P/Q/E communication


If some of the IDUs in the same refrigerant system are 1st Generation Atom series, it is required to connect "P", "Q", and "E" for P/Q/E communication.

Single unit: Use a shielded cable for the P/Q/E communication and properly ground the shield layer. P, Q, and E ports are located at terminal block "CN6" of the main control board. There is no distinction between negative and positive electrodes. Connect the shield layer to the sheet metal of the electric control box, as shown in the following figure:



Connect to the ODU PQE

System: The maximum total length of the P/Q/E communication cable of the IDU and ODU can be up to 1200m, and can be connected in serial, as shown in the figure below:



L1+La+Ln ≤ 1200m

[Caution]

When P/Q or P/Q/E communication is used, the IDUs need to be powered uniformly.

Use only shielded cables for P/Q or P/Q/E communication. Otherwise, the IDU and ODU communication may be affected.


A matching resistor needs to be added to the last IDU on the PQ (in the accessory bag of the ODU).





4. X1/X2 communication cable connection

The X1X2 communication line is mainly connected to the wired controller to achieve one controller per IDU and two controllers per IDU. The total length of the X1X2 communication line can reach 200 meters. Please use shielded wires, but the shield layer cannot be grounded. X1 and X2 ports are located at terminal block "CN6" of the main control board. There is no distinction between negative and positive electrodes. For details, see the following figure:



 $L1 \le 200 \text{m}, L2 + L3 \le 200 \text{m}.$

[Caution]

Two wired controllers of the same model can be used to control one IDU at the same time. In this case, you need to set one controller to be the master and the other to be the slave. For details, see the wired controller manual.






5. D1D2 communication line connection (limited to ODU and system configuration)

A Achieving one-to-multiple and two-to-multiple functions of the IDU wired controller through D1D2 communication (a maximum of 16 sets)

D1D2 communication is 485 communication. The one-to-more and two-to-more functions of the IDU wired controller can be achieved through D1D2 communication, as shown in the figure below:



L1+L2 ≤ 200m, L3+Ln ≤ 1200m


[Caution]

When the IDUs in the same refrigerant system are 2nd Generation Atom IDUs, D1D2 communication can enable one-to-multiple and two-to-multiple functions of the IDU wired controller.

To enable two-to-multiple functions, wired controllers must be of the same model.

B Achieving centralized control of the IDU through D1D2 communication

The D1D2 communication line can also be connected to the centralized controller to achieve centralized control of the IDU, as shown in the figure below:



L1+L3+Ln ≤ 1200m








External board connection (limited to ODU and system configuration)

The external board is a connection module outside the main control board, including a function module adapter board, and optional function expansion boards 1 and 2.

1. Display panel connection


The display panel is connected to the main control board through a 4-core cable, and is connected to the "CN30" socket of the main control board, as shown in the following figure:




2. Function module adapter board connection

Function expansion boards can communicate with the main control board through the adapter board. You can use one or both of the two function expansion boards. The wiring diagrams are as follows:


Use function expansion board 1#



Use function expansion board 2#



Use function expansion boards 1 and 2





For the function introduction of the function module adapter board, function expansion board 1#, and function expansion board 2#, please refer to the function module manual.








Reclose the electric control box cover

Straighten out the connecting wires and lay them flat, and separate and fix the strong- and weak-current cables with cable clamps.



[Caution]

Do not cover the electric control box during power-on.

When covering the electric control box, arrange the cables carefully and do not clip the connecting wires on the electric control box cover.







Application Control

Error Codes and Definitions

In the following circumstances (warning failures excluded), please stop the air conditioner immediately, cut off the power switch and contact the local air conditioner customer service center. The error code is displayed on the display panel and the wired controller display.

| Error | Error code | Digital display |
|--|------------|-----------------|
| Emergency stop | A01 | |
| R32 refrigerant leaks, requiring shutdown immediately | A11 | |
| ODU fault | A51 | |
| The fault of the linked FAPU is transmitted to the master IDU (series setting) | A71 | |
| The fault of the linked humidifying IDU is transmitted to the master IDU | A72 | |
| The fault of the linked FAPU is transmitted to the master IDU (non-series setting) | A73 | |
| The fault of the AHU Kit slave unit is sent to the master unit | A74 | |
| Self-check fault | A81 | |
| MS (refrigerant flow direction switching device) fault | A82 | BBB |
| Mode conflict (1st Generation Atom communication protocol adopted) | A91 | |
| 1# EEV coil fault | b11 | |
| 1# EEV body fault | b12 | |
| 2# EEV coil fault | b13 | |
| 2# EEV body fault | b14 | |
| Stall protection on 1# water pump | b34 | BBB |
| Stall protection on 2# water pump | b35 | 888 |
| Water level switch alarm | b36 | 888 |
| Reheating electric heater fault | b71 | BBB |
| Preprocessing electric heater fault | b72 | |
| Humidifier fault | b81 | |
| Duplicate IDU address code | C11 | |





| Error | Error code | Digital display |
|---|------------|-----------------|
| Abnormal communication between the IDU and ODU | C21 | |
| Abnormal communication between the IDU main control board and fan drive board | C41 | |
| Abnormal communication between the IDU and wired controller | C51 | |
| Abnormal communication between the IDU and Wi-Fi Kit | C52 | |
| Abnormal communication between the IDU main control board and display board | C61 | |
| Abnormal communication between the AHU Kit slave unit and master unit | C71 | |
| Number of AHU Kits is not the same as the set number | C72 | |
| Abnormal communication between the linked humidifying IDU and master IDU | C73 | |
| Abnormal communication between the linked FAPU and master IDU (series setting) | C74 | |
| Abnormal communication between the linked FAPU and master IDU (non-series setting) | C75 | |
| Abnormal communication between the main wired controller and secondary wired controller | C76 | |
| Abnormal communication between the IDU main control board and 1# function expansion board | C77 | |
| Abnormal communication between the IDU main control board and 2# function expansion board | C78 | |
| Abnormal communication between the IDU main control board and adapter board | C79 | |
| Air inlet temperature of the IDU is too low in heating mode | d16 | |
| Air inlet temperature of the IDU is too high in cooling mode | d17 | |
| Alarm for exceeding temperature and humidity range | d81 | |
| Sensor control board fault | dE1 | |
| PM2.5 sensor fault | dE2 | |
| CO2 sensor fault | dE3 | |
| Formaldehyde sensor fault | dE4 | |
| INTELLECTUAL EYE sensor fault | dE5 | |
| T0 (fresh inlet air temperature sensor) short-circuits or cuts off | E21 | BBB |
| The upper dry bulb temperature sensor short-circuits or cuts off | E22 | BBB |
| The lower dry bulb temperature sensor short-circuits or cuts off | E23 | BBB |
| T1 (IDU return air temperature sensor) short-circuits or cuts off | E24 | BBB |





| Error | Error code | Digital display |
|---|------------|-----------------|
| The built-in room temperature sensor of the wired controller short-circuits or cuts off | E31 | BBB |
| The wireless temperature sensor short-circuits or cuts off | E32 | BBB |
| The external room temperature sensor short-circuits or cuts off | E33 | 888 |
| Tcp (pre-cooled fresh air temperature sensor) short-circuits or cuts off | E61 | BBB |
| Tph (pre-heated fresh air temperature sensor) short-circuits or cuts off | E62 | |
| TA (outlet air temperature sensor) short-circuits or cuts off | E81 | |
| Outlet air humidity sensor fault | EA1 | |
| Return air humidity sensor fault | EA2 | BBB |
| Upper wet bulb sensor fault | EA3 | BBB |
| Lower wet bulb sensor fault | EA4 | BBB |
| R32 refrigerant leakage sensor fault | EC1 | |
| T2A (heat exchanger inlet temperature sensor) short-circuits or cuts off | F01 | |
| T2 (heat exchanger middle temperature sensor) short-circuits or cuts off | F11 | |
| T2 (heat exchanger middle temperature sensor) overtemperature protection | F12 | |
| T2B (heat exchanger outlet temperature sensor) short-circuits or cuts off | F21 | |
| Main control board EEPROM fault | P71 | |
| IDU display control board EEPROM fault | P72 | |
| Locked (electronic lock) | U01 | |
| Unit model code not set | U11 | |
| Horsepower code not set | U12 | |
| Horsepower code setting error | U14 | |
| AHU Kit fan control input signal DIP setting error | U15 | |
| Address code not detected | U38 | |
| Motor failed more than once | J01 | |
| IPM (fan module) overcurrent protection | J1E | BHB |
| Instantaneous overcurrent protection for phase current | J11 | |





| Error | Error code | Digital display |
|----------------------------------|------------|-----------------|
| Low bus voltage fault | J3E | |
| High bus voltage fault | J31 | |
| Phase current sample bias error | J43 | |
| Motor and IDU are unmatched | J45 | |
| IPM and IDU are unmatched | J47 | |
| Motor startup failure | J5E | |
| Motor blocking protection | J52 | |
| Speed control mode setting error | J55 | |
| Phase lack protection of motor | J6E | |

Operating Status Codes and Definitions (Non-Error)

| Definition | Code | Digital display |
|--|------|-----------------|
| Oil return or preheating operation | d0 | |
| Self-cleaning | dC | |
| Mode conflict (2 nd Generation Atom communication protocol adopted) | dd | |
| Defrosting | dF | |
| Static pressure detection | d51 | |
| Remote shutdown | d61 | |
| IDU backup operation | d71 | |
| ODU backup operation | d72 | |
| Main control program upgrading | ОТА | |

[Caution]

Error codes are displayed only for certain ODU models and IDU configurations (including the wired controller and display panel).

When the main control program is being upgraded, make sure that the IDU and ODU remain powered on. Otherwise, the upgrading process will stop.






Spot Check Description

Use the bi-directional communication wired controller (for example, WDC3-86S) to activate the spot check function in the following steps:

- 1. On the main page, hold " ≡ " and " ▲ " for 2s to enter the query page. The ODU displays u00-u03, the IDU displays n00-n63 (the last two digits show the IDU address), and the wired controller displays CC. Press the " ▲ " or " ▼ " key to select the IDU, and press the " ▽ " key to enter the parameter query page.
- 2. Press the "▲" or "▼" key to query the parameters, and the parameters can be queried cyclically. See the spot check list below for details.
- 3. Press the " \(\bigcap \)" key to exit the query function.
- 4. On the top of the query page, the "Timing area" displays the spot check serial number, and the "Temperature area" displays the content of the spot check parameters.



| No. | Displayed content | No. | Displayed content |
|-----|--|-----|-------------------------------------|
| 1 | IDU and ODU communication address (current IDU addresses are displayed every 0.5s) | 13 | Compressor discharge temperature |
| 2 | Capacity HP of IDU | 14 | Target overheating |
| 3 | Actual set temperature Ts | 15 | EEV opening (actual opening/8) |
| 4 | Current running set temperature Ts | 16 | Software version No. |
| 5 | Actual T1 indoor temperature | 17 | Display board version No. |
| 6 | Modified indoor temperature T1_modify | 18 | Fan drive version No. |
| 7 | T2 heat exchanger intermediate temperature | 19 | Historical error code (recent) |
| 8 | T2A heat exchanger liquid pipe temperature | 20 | Historical error code (sub-recent) |
| 9 | T2B heat exchanger gas pipe temperature | 21 | IDU network address display |
| 10 | Actual set humidity RHs | 22 | IDU expansion board address display |
| 11 | Actual RH indoor humidity | 23 | [———] is displayed |
| 12 | Real-time static pressure | | |





5 Test Run

Before the Test Run, Make Sure That

- · IDUs and the ODU are properly installed.
- · The piping is correct, and the refrigerant piping system has been checked for leakage.
- · Piping length and the amount of refrigerant charged have been recorded.
- The wiring is correct and firm without virtual connection issues. Ground wires have been properly connected.
- The voltage of the power supply is the same as the rated voltage of the air conditioner.
- · Heat insulation is complete.
- · There are no obstructions at the air inlet and outlet of the IDU and ODU.
- Fully open the check valves of the gas pipe and liquid pipe of the ODU.
- · Turn on the power supply to preheat the ODU for 12 hours.

Test Run

Use the wired/remote controller to control the cooling or heating operation of the air conditioner according to the instructions.

In the event of a failure, please troubleshoot according to the "Symptoms That Are Not Faults" in the "Precautions for Use" in this manual.



Follow the trial run steps of the ODU.

IDU

- · The wired/remote controller switch is operating normally.
- The display of the wired/remote controller is normal, the function keys work normally, the room temperature adjustment is normal, and the air flow and direction adjustment are normal.
- · The LED indicator is on.
- · Water discharge is normal.
- Check the IDUs one by one for normal operation, and the cooling and heating functions are normal without vibration or abnormal sound.

ODU

- There are no vibrations or strange sounds during operation.
- The fan, noise and condensation do not affect the neighbors.
- · There is no refrigerant leakage.





Inspection After Installation

To ensure a comfortable indoor environment, please run down through the list to check whether the installation of the air conditioner meets the requirements. Insert a " \times " for Fail and a " \sqrt " for Pass.

| Check Item | Check Criteria | Check Result (Pass/Fail) |
|--|--|-----------------------------|
| Are the IDUs and ODUs securely installed? | The air conditioner does not fall or vibrate, and there is no noise. | |
| Has the installation of the IDU been completed? | The unit works properly and no parts are burned out. | |
| Has a leak test been performed? | The cold/hot air is sufficient. | |
| Is the heat insulation in good condition (refrigerant piping, drainage pipe, and air ducts)? | There is no condensation dripping. | |
| Were the copper pipes sealed before installation to prevent dust from entering? | The compressor is functional. | |
| Is the refrigerant piping filled with nitrogen for shielded welding during the welding process (a nitrogen cylinder is on site)? | There is no oxide film on the inner surface of the copper pipe. The system is functional with no major failures. | |
| Has a water discharge test been performed? Is drainage smooth? Is the connection secure? | There is no water leakage. | |
| Is the power supply voltage consistent with the specified voltage on the unit nameplate? | The unit works properly and no parts are burned out. | |
| Are the wires and pipes connected correctly? | The unit works properly and no parts are burned out. | |
| Is the air conditioner safely grounded? | There is no electric leakage. | |
| Have wires of the specified size been used? | The unit works properly and no parts are burned out. | |
| Are the terminal screws securely fastened? | There is no electric shock or fire. | |
| Are the inlets and outlets of the IDUs and ODUs free of obstruction? | The cold/hot air is sufficient. | |
| Has the refrigerant piping length and refrigerant charge been recorded? | The amount of refrigerant in the air conditioning system is clear. | |
| Does the temperature of each room meet the requirements during testing? | Users' comfort needs can be satisfied. | |
| Have you explained to the user how to operate the unit according to the user manual? | The unit is effective. | |
| Have you explained to the user how to use and clean the air filter? | The unit is effective. | |





Cleaning, Maintenance and After-Sales Service

1 Safety Warning

(Marning)

For safety reasons, always turn off the air conditioner and turn off the power before cleaning the air conditioner.

Do not disassemble or repair the air conditioner by yourself; otherwise, it may cause fire or other hazards.

Only professional service personnel can carry out the maintenance.

Do not use flammable or explosive materials (such as hair styling agents or pesticides) near the product.

Do not use organic solvents such as paint thinner to clean this product; otherwise, it may cause cracks, electric shock or fire.

Only qualified dealers and professionally qualified electricians can install the optional accessories.

Be sure to use the optional accessories specified by our company.

Improper installation by yourself may result in water leakage, electric shock or fire.

Do not wash the air conditioner with water; otherwise, it may cause an electric shock.

Use a stable standing platform.

2 Cleaning and Maintenance

Cleaning the Louver and Unit Surface

- Clean the cloth in water, wring out the cloth, and gently wipe the unit body.
- (2) If a stain is hard to remove, dip a cloth into neutral detergent and clean the stain.

[Caution]

Do not use gasoline, benzene, volatile agents, decontamination powder or liquid insecticides. Otherwise, the air outlet or panel may become discolored or deformed.

Do not expose the inside of the IDU to moisture, as it may result in electric shock or fire.

When cleaning the louver with water, do not scrub it violently.

If the air conditioner is used without an air filter, the accumulation of dust in the air conditioner will often cause malfunctions due to the failure to remove dust from the indoor air.





Cleaning the Air Filter

[Caution]

Air filters can be used to remove dust or other particles from the air, and if clogged, the effectiveness of the air conditioner will be greatly reduced.


Therefore, be sure to clean the air filter frequently when using it for an extended period. If the unit is installed in a place with a lot of dust, it is recommended that you clean the filter once a month.

If excess dirt makes the filter difficult to clean, replace the filter.

Do not remove the air filter unless it is being cleaned; otherwise, it may cause malfunction.


1 Procedure diagram

Use two hands to hold the panel above theair outlet, open it in the direction of the arrow, and use one hand to hold the panel and the other hand to lift the middle convex part of the filter and pull the filter out downwards.



(2) Clean the filter and dry it in a cool place.

Clean the filter with a vacuum cleaner, with the air inlet side of the filter facing upwards.



Clean the filter with clean water (except for the activated carbon module), with the air inlet side of the filter facing downwards.



[Caution]

To avoid deformation of the filter, do not use fire or a burning appliance to dry the filter.

If the filter is heavily soiled, use a soft brush and neutral detergent to clean it, then shake off the water and dry it in a cool place.

Non-professionals should not disassemble, replace or repair the filter.

3 Reinstall the filter in the reverse order of the steps above and put the panel back.





Maintenance

During in-depth maintenance, the air conditioner should be cleaned and maintained by professional technicians every 2 to 3 years.

Clean the filter regularly.

When operating in a dusty environment, the air flow and capacity of the filter will decrease. The filter may even become blocked, and the air conditioner performance and indoor air compromised.

Preheat the unit in advance.

When the heating season comes, power on the ODU master unit for preheating more than 4 hours before use. The preheating time depends on the weather temperature. This can make the air conditioner operate more stably and help the refrigeration oil in the air conditioner compressor to maintain the best lubrication state, which can prolong the service life of the compressor.

Complete the following steps before the air conditioner is put out of use for a long period:

- 1. If the air conditioner is not in use for a long time due to seasonal changes, keep the unit running for 4-5 hours in fan mode until the unit becomes completely dry. Otherwise, it may grow mold indoors and have negative health effects.
- 2. When not in use for a long time, power off or unplug the power plug to reduce standby power consumption, and wipe the wireless remote controller with a clean soft dry cloth and remove the battery.
- 3. Turn on the power switch 12 hours before using the air conditioner again. In addition, in seasons when air conditioners are frequently used, keep the power switch on. Otherwise, failures may occur.



Before the air conditioner is idle for a long time, the internal components of the ODUs should be checked and cleaned regularly. For more details, please contact the local air conditioner customer service center or special technical service department.

Check the return air inlet and outlet of the ODU and IDU after long periods of use to see if they are blocked; if an inlet/outlet is blocked, clean it immediately.






3 Maintenance of Conventional Parts


Disassembly and Installation of Panel and IDU Wiring

1 Disassembly of the Front Panel

There is no need to disassemble the panel frame when confirming the electrical cable distribution and condensed water drainage.


- 1) Pull out slightly on the panel from the buckle position on both sides of the unit body.
- ② Take the panel off the buckles along the gap between the panel and the unit body. Remove the panel obliquely upward.
- ③ Hold the two lower ends of the front panel, gently pull the panel and then push the panel upward to remove it.





2 IDU wiring
Lead the power cable, ground wire, and signal cable from the back of the indoor unit to the front. For detailed wiring steps, refer to section "Installation Instructions - Electrical Connection".

- 3 Installation of Front Panel
 - ① Insert the upper buckles of the panel into the buckles on the panel frame.
 - 2 Place the panel and press the buckles.






Make sure that the front buckles of the panel fit the unit well, otherwise condensation and other risks may occur.






Replacement of the Filter

1 Open the panel assembly.




2 Remove and replace the filter.





Maintenance of the Electric Control Board

1 Dismantle the panel assembly.




2 Loosen the screws on the right side of the electric control box cover and remove the electric control box cover.





Loosen the screws inside the electric control box, remove the main control board and start repairing the unit.









Maintenance of Display Panel

- 1 Follow the steps above to dismantle the panel assembly.
- 2 First remove the display box cover, then remove the display panel and unplug the cable.




Maintenance of Infrared Human Sensor, Temperature Sensor, Drain Pump and Water Level Switch


Remove the upper and lower louver near the screw hole, loosen the screws, and then remove the panel frame.



Take out the infrared human sensor, remove the connecting cable and repair the sensor.



Pull the temperature sensor out of the buckle or sleeve, pull the plug out of the electric control box and repair the temperature sensor.









- 4 Plasma generator (optional):
 - 1 Remove the screws (two).
 - 2 Pull out the electrode, remove the plasma generator and repair it.

Humidity sensor: Remove the humidity sensor cable from the electric control board, pull out the humidity sensor and repair it.

Electronic expansion valve coil: Remove the electronic expansion valve coil cable from the electric control board, pull out the coil and repair it.



Remove the water pump and water level switch cable from the electric control board, ① pull out the drainage pipe from the chassis outlet, ② loosen the two screws fixing the drain pump mounting base, remove the drain pump assembly, ③ loosen the screws securing the drain pump, remove the drain pump to repair it, and ④








Maintenance of Motor and Wind Wheel


Pull the plug of the motor, electronic expansion valve and each temperature sensing line out of the electric control board, pull out the drainage pipe from the chassis outlet, push the buckle of the drain pan assembly upward so that the buckle is separated from the chassis, and then pull the drain pan assembly out horizontally.




[Caution]

Dismantle the motor cable at position A before you dismantle the drain pan assembly. The sensor cable at position B may not be removed. Carefully hang the drain pan assembly.

Lift and pull out the box containing the silver ion deodorizer for maintenance.




3 Loosen the screw (one), pull the evaporator horizontally a little and hang the evaporator.








4 Loosen the screws (two), swivel out slightly and take out the motor mounting rack (hold the motor and prevent it from falling). Pull out the motor and wind wheel horizontally.



Take the motor and wind wheel out horizontally; loosen the screws fixing the motor and wind wheel, and repair the motor and wind wheel.








Maintenance of Wind Wheel Bearing

1 Follow the steps above to remove the motor and wind wheel; push the wind wheel bearing to remove and repair it.









Maintenance of Oscillation Motor

Follow the steps above to remove the panel frame and upper and lower louvers.



First loosen the screws (three) to remove the display panel, remove the cable terminal on the oscillation motor, then disconnect the left and right louver rod and the left and right swing motor rod, and take the swing motor and repair it.











PÓLIZA DE GARANTÍA LA SYSTEMS

Atención: Leer cuidadosamente el manual de mantenimiento e instalación y ponerlos en práctica, le brindará lo necesario para un funcionamiento adecuado de su equipo. Para validar la garantía favor de acudir directamente con el distribuidor autorizado que le vendió este equipo.

Se validará la garantía bajo las siguientes condiciones:

Cláusulas

- Requisitos. Para validar su garantía, se deberá presentar la póliza debidamente sellada por distribuidor autorizado que vendió este producto o en su caso, copia respectiva de la factura o recibo que acredite la compra-venta de su unidad.
- Producto. Esta póliza de garantía es exclusivamente para el producto adquirido y cuyo número de serie está identificado tanto en unidades exterior (condensadora) e interior (evaporadora), así como en los empaques de los mismos. Se recomienda conservar estas etiquetas para futuras aclaraciones.
- 3. Vigencia y alcance. La vigencia de esta póliza de garantía es de 3 meses en partes electrónicas (tarjetas, display y control remoto), 12 meses en el resto de partes (motores, aspas, serpentines, compresor, etc), a partir de la adquisición del producto; se extiende única y exclusivamente a fallas o defectos de fabricación.
- 4. La instalación, reparación y manipulación de esta unidad deberá ser realizada por personal calificado y autorizado por nuestras marcas.

La garantía de este producto no será válida en las siguientes situaciones:

- a) Cuando el producto haya sido instalado de manera diferente a la que se expresa en este manual.
- b) Cuando el producto haya sufrido daños por problemas climatológicos, ambientales o desastres naturales.
- c) Cuando presente daños en su estructura debido al mal manejo de la unidad.
- d) Cuando el producto sea destinado para fines distintos a los indicados en el manual.
- cuando el producto no sea instalado y/o utilizado de acuerdo a las especificaciones que se indican en el manual de usuario.
- f) Cuando el producto sea instalado, alterado o reparado por personal no autorizado por la marca.
- g) Cuando el producto no se encuentre el periodo de garantía especificado en esta póliza.
- h) Por la implementación de accesorios que no correspondan a la marca.
- i) Cuando el producto sea instalado para fines comerciales y no domésticos.
- j) Cuando la unidad sea desinstalada.

Refacciones

- Las refacciones y componentes empleados para la reparación de su unidad no tendrán costo extra únicamente cuando estén sujetos a esta póliza de garantía, de igual forma se cubrirán los gastos de transportación y mano de obra que se deriven del fallo que se presente.
- El consumidor puede obtener partes, componentes, consumibles y accesorios con el distribuidor autorizado que vendió en la zona.

Atención y servicio. Esta garantía podrá ser atendida únicamente por el distribuidor que vendió el producto. Cuando el producto se haya adquirido en cadenas comerciales, la garantía se hará válida en los centros de servicio autorizados, mismos publicados en www.unitedappliances.com. Para más información llame al Tel. 800-788-4040 o comuníquese vía correo electrónico: soporte.tecnico@unitedappliances.com, Por estos medios se le brindará la información que se requiera.

ALLOSTE S.A DE C.V se deslinda de responsabilidad alguna al momento en que se presente un fallo en el equipo por instalaciones defectuosas o erróneas realizadas por personal no autorizado.







CENTROS DE ATENCIÓN DIRECTA A CLIENTES:

(Distribuidor / Comercializador Autorizado) Sello de Garantía del Distribuidor

| DATOS DE DIS | STRIBUIDOR / COMERCIALIZADOR AUTORIZADO: |
|---------------|--|
| Razón Social: | |
| Dirección: | |
| | DATOS DEL ARTÍCULO: |
| Marca: | |
| Modelo: | |
| | FIRMA DEL TÉCNICO INSTALADOR: |
| Nombre: | |
| E-Mail: | |
| Teléfono: | |





| M HYAC SYSTEMS | | | | |
|--|-----------------|--------------|-----------------|--|
| ACC | ONDICIONADOR | DE AIRE | VRF | |
| TIPO M | ULTI SPLIT SUB | TIPO INV | /ERTER | |
| UNIDAD EVAPORA | ADORA HIGH WALL | MARCA: U | JA HVAC SYSTEMS | |
| MODELO EV | /APORADORA: (| JAVHWH | 009DD300E1/I | |
| 1 FASE 220/240V~ 50/60Hz | | |)/60Hz | |
| CAPACIDAD DE ENFRIAMIENTO: | | 9 000 BTU/h | | |
| CAPACIDAD DE CALEFACCIÓN: | | 10 000 BTU/h | | |
| POTENCIA DE ENTRADA EN ENFRIAMENTO: | | 24 W | | |
| POTENCIA DE ENTRADA EN CALEFACCIÓN: | | 24 W | | |
| CORRIENTE NOMINAL: | | 0,36 A | | |
| REFRIGERANTE: | | R410A | | |

IMPORTADO POR: ALLOSTE, S.A. DE C.V.

HECHO EN CHINA

Boulevard Insurgentes No. 18302-3, Colonia El Lago. Tijuana, B.C., México, C.P. 22210. R.F.C.: ALO201127UZ4 Tel: +52 (664) 830-1323

MUY IMPORTANTE: DEBE SER OPERADO POR UN ADULTO NO DEBE SER OPERADO POR UN MENOR Ó GENTE CON CAPACIDADES DIFERENTES. ESTE APARATO NO ES UN JUGUETE VER INSTRUCTIVO ANEXO

www.uahvacsystems.com

| LA HYAC SYSTEMS | | | | | | | |
|--|-----|----------------|-----------------|--|--|--|--|
| ACONDICIONADOR DE AIRE VRF | | | | | | | |
| TIPO MULTI SPLIT SUBTIPO INVERTER | | | | | | | |
| UNIDAD EVAPORADORA HIGH WALL MARCA: U | | | JA HVAC SYSTEMS | | | | |
| MODELO EVAPORADORA: UAVHWH012DD300E1/I | | | | | | | |
| 1 FASE | 220 | /240V~ 50/60Hz | | | | | |
| CAPACIDAD DE ENFRIAMIENTO: | | | 12 000 BTU/h | | | | |
| CAPACIDAD DE CALEFACCIÓN: | | | 13 000 BTU/h | | | | |
| POTENCIA DE ENTRADA EN ENFRIAMENTO: | | | 27 W | | | | |
| POTENCIA DE ENTRADA EN CALEFACCIÓN: | | | 27 W | | | | |
| CORRIENTE NOMINAL: | | | 0,39 A | | | | |
| REFRIGERANTE: | | | R410A | | | | |

HECHO EN CHINA

IMPORTADO POR: ALLOSTE, S.A. DE C.V.

Boulevard Insurgentes No. 18302-3, Colonia El Lago. Tijuana, B.C., México, C.P. 22210. R.F.C.: ALO201127UZ4 Tel: +52 (664) 830-1323

MUY IMPORTANTE: DEBE SER OPERADO POR UN ADULTO NO DEBE SER OPERADO POR UN MENOR Ó GENTE CON CAPACIDADES DIFERENTES. ESTE APARATO NO ES UN JUGUETE VER INSTRUCTIVO ANEXO

www.uahvacsystems.com





| ₩ HYAC SYSTEMS | | | | | | |
|--|-------------------|--|-----------------|--|--|--|
| ACONDICIONADOR DE AIRE VRF | | | | | | |
| TIPO MULTI SPLIT SUBTIPO INVERTER | | | | | | |
| UNIDAD EVAPORADORA HIGH WALL MARCA: U | | | JA HVAC SYSTEMS | | | |
| MODELO EVAPORADORA: UAVHWH018DD300E1/I | | | | | | |
| 1 FASE | 220/240V~ 50/60Hz | | | | | |
| CAPACIDAD DE ENFRIAMIENTO: | | | 19 000 BTU/h | | | |
| CAPACIDAD DE CALEFACCIÓN: | | | 21 000 BTU/h | | | |
| POTENCIA DE ENTRADA EN ENFRIAMENTO: | | | 40 W | | | |
| POTENCIA DE ENTRADA EN CALEFACCIÓN: | | | 40 W | | | |
| CORRIENTE NOMINAL: | | | 0,51 A | | | |
| REFRIGERANTE: | | | R410A | | | |

HECHO EN CHINA

IMPORTADO POR: ALLOSTE, S.A. DE C.V.

Boulevard Insurgentes No. 18302-3, Colonia El Lago. Tijuana, B.C., México, C.P. 22210. R.F.C.: ALO201127UZ4 Tel: +52 (664) 830-1323

MUY IMPORTANTE: DEBE SER OPERADO POR UN ADULTO NO DEBE SER OPERADO POR UN MENOR Ó GENTE CON CAPACIDADES **DIFERENTES. ESTE APARATO NO ES UN** JUGUETE VER INSTRUCTIVO ANEXO

www.uahvacsystems.com

| L ASYSTEMS | | | | | | |
|--|-------------------|-----------------|--|--|--|--|
| ACONDICIONADOR DE AIRE VRF | | | | | | |
| TIPO MULTI SPLIT SUBTIPO INVERTER | | | | | | |
| UNIDAD EVAPORADORA HIGH WALL MARCA: U | | JA HVAC SYSTEMS | | | | |
| MODELO EVAPORADORA: UAVHWH028DD300E1/I | | | | | | |
| 1 FASE | 220/240V~ 50/60Hz | | | | | |
| CAPACIDAD DE ENFRIAMIENTO: | | 27 000 BTU/h | | | | |
| CAPACIDAD DE CALEFACCIÓN: | | 30 000 BTU/h | | | | |
| POTENCIA DE ENTRADA EN ENFRIAMENTO: | | 65 W | | | | |

POTENCIA DE ENTRADA EN CALEFACCIÓN:

CORRIENTE NOMINAL:

REFRIGERANTE:

HECHO EN CHINA

65 W

0,98 A

R410A

IMPORTADO POR: ALLOSTE, S.A. DE C.V.

Boulevard Insurgentes No. 18302-3, Colonia El Lago. Tijuana, B.C., México, C.P. 22210. R.F.C.: ALO201127UZ4 Tel: +52 (664) 830-1323

MUY IMPORTANTE: DEBE SER OPERADO POR UN ADULTO NO DEBE SER OPERADO POR UN MENOR Ó GENTE CON CAPACIDADES **DIFERENTES. ESTE APARATO NO ES UN** JUGUETE VER INSTRUCTIVO ANEXO

www.uahvacsystems.com



IMPORTADO POR:

ALLOSTE, S.A. DE C.V.

Blvd. Insurgentes #18302-3 Col. El Lago C.P. 22210 Tijuana. B.C. México.

R.F.C. ALO201127UZ4